







# AXLE NUTS

PART NO.	NOTES	O.D.	I.D.	THK	REPLACES
 <b>3570</b>	Lock  Eaton/Dana 10,12,13, 14,000#	3"	1-1/2"	.048"	Batco BWP Eaton Euclid Leland Meritor  817134 L-3570
 <b>3571</b>	Lock Washer  Eaton/Dana 10,12,13, 14,000#	2-3/4"	1-1/2"	.187"	Batco BWP Eaton Euclid Leland Meritor  815623 L-3571
 <b>5210</b>	Inner Nut "Trade" Axles  Use Wrench 1927	3-13/16"	2-5/8" - 16	3/8"	Batco BWP Euclid Leland Meritor Spicer Std Forge 06-203 M-682 E-540 L-176 1227C549 12-391 M10HN101 103103-002
 <b>5200</b>	Outer Nut "Trade" Axles  Use Wrench 1909	3-1/4"	2-5/8" - 16	3/8"	Batco BWP Euclid Leland Meritor Spicer Std Forge 06-201 M-684 E-572 L-178 1227B756 12-393 M10HN102 103102-001
 <b>5660</b>	Tab Lock Washer "Trade" Axles  5/32" Tab	4-1/32"	2-41/64"	1/16"	Batco BWP Euclid Leland Meritor Spicer Std Forge 06-230 M-1068 E-2237 L-1327 R002237 12-394 M10HN151 105106
 <b>5300</b>	Lock Washer "Trade" Axles	3-15/16"	2-41/64"	1/4"	Batco BWP Euclid Leland Meritor Spicer Std Forge 06-202 M-683 E-573 L-177 R000573 12-392 M10HN100 105107

Copyright 2005 Sirco Industries, Inc.